




SCK GND
TP44 TP45
R40 TP48
3V8 TP40 PWDN
SDA0 TP46
SCL0 TP47 Cam_VDD

USB_ON/OFF

CLK2 DAT2
TP41 TP42



TP49 SD_VDD
SD 2.0



C6 R5

